

# RG25 Regulator

## Replacement Regulator for

## Nippon Denso type fan cooled alternators



### INSTALLATION INSTRUCTIONS

#### READ THESE INSTRUCTIONS CAREFULLY

**Step 1** Remove plastic housing from alternator by taking out the 3 screws indicated S1, S2, and S3 as shown in figure 1.

**Step 2** Extract original regulator device from housing by removing the two screws from the top. Cut the 2 connections on the underside.

**Step 3** Replace the housing on the alternator. The new RG25 regulator fits as shown (see figure 2). Use spacer and screw provided.

**Step 4** Connect cables as shown (see figure 2) using existing screws (S2 and S3).

